



- PLUMBER**
- REMOVE CAP
 - INSTALL 100MM LINE CLEAN-OUT
 - CONNECT TO SUMP PUMP
 - TO BE INSPECTED BY BUILDING DEPARTMENT

- DRAIN LAYER**
- APPLY FOR SEWER PERMIT FROM BUILDING DEPARTMENT
 - INSTALL 100MM PIPE TO GRADE COMPLETE WITH CAP
 - TO BE INSPECTED BY BUILDING DEPARTMENT

NOTES 1. FOR STORM SEWER LATERAL LOCATION AT PROPERTY LINES SEE SERVICING DRAWINGS.

**SUMP PUMP WITH
 STORM DRAIN
 CONNECTION**